

HOW TO...

Open the Yukon TV app:

Press the **My TV** button  on your remote

Set a recording:

- 1 Press the **Guide** button  on your remote
- 2 Select show
- 3 Press the **Record** button  and follow on-screen prompts

Access Video on Demand:

- 1 Press the **Menu** button  on your remote
- 2 Select "VOD"

Make a direct channel change:

Use the 0 – 9 buttons on your remote while in LiveTV or Guide to tune directly to a channel. All of your favorite channels are available on Yukon TV, in 100% HD format. View channel lineups through the Guide or at gci.com/tv/channel-line-up.

Additional support available at gci.com/support.

View the complete Yukon TV channel lineup.

Visit gci.com/tv/channel-line-up

Personalize your Yukon TV package with more of the content you love.

Genre tiers and premium channels are available to upgrade your experience.

Explore your options at gci.com/tv

Let your Yukon TV experience take you further.

Upgrade your viewing features to include more simultaneous streams and cloud DVR hours.

Need help?

Just give us a call:

800.800.4800



Getting Started with Yukon TV

on EVO PRO Streaming Device

Alaska's Ultimate Streaming Experience



STEP-BY-STEP GUIDE

1 Package Contents:

- 1 EVO PRO device
- 2 EVO PRO Quick Guide
- 3 Remote with batteries
- 4 HDMI cable
- 5 Power Cord



2 Use the HDMI cable to connect the EVO PRO device to your TV.

3 Using the power cord, plug in the EVO PRO.

4 Follow the on-screen instructions using your remote to navigate through the setup process. You'll need:

- A Yukon TV account and GCI Home Internet.
Note: Streaming on Yukon TV does not count against your GCI home internet usage.
- A Google account to complete the EVO PRO setup.
Note: You are able to register for a Google account on the EVO PRO when getting started.
- To be registered on MyGCI.
Note: Visit my.gci.com to get started.

5 Download the Yukon TV app by pressing the My TV button on your remote.

6 Sign into your Yukon TV account using your MyGCI login credentials.

7 Reboot the EVO PRO device.

- Navigate to Device Settings → Device Preferences → Reboot
- This step will ensure that the Yukon TV app will automatically open when the EVO PRO is turned on.

8 Start watching your favorite shows on Yukon TV!

Remember to add the Yukon TV app to the app row by selecting the + icon on the Android TV home page.

After completing installation, →
tear off this sheet to use as a quick reference guide for your remote.

YUKON TV REMOTE GUIDE

